


## Silhouette Cameo – Loading and Unloading Media


### Step 1: When to use a cut mat instead

- The “Load Media” option is for materials not needing a cut mat. Only use the “Load Media” option for materials with a backing – for example, sticker paper.
- Materials that will be cut all the way through – for example paper and cardstock, must be cut on a cut mat.



### Step 2: Align the material with the rollers

- Align the edge of the material with the blue line on the Silhouette. Make sure the top edge of the material is under both of the white rollers.



### Step 3: Load the material

- Press the “Load Media” option on the Silhouette’s touch screen.



### Step 4: Check for proper loading

- If one of the rollers grabs the material sooner than the other, it can load slightly crooked. The first picture shows properly loaded material, the second shows material that did not load straight. If the material does not load straight, unload it and try again, making sure the material has contact with both of the white rollers before pressing the “Load Media” button.



### Step 5: Unloading the material

- To unload when a project is finished, press the “Unload” option on the Silhouette’s touch screen.

